



To help you make the most of your new Dimplex Electric Heater

## Manual Input Storage Heaters

XL/XLN Models

### Input control - controls the temperature of the heater


Set to maximum during coldest weather. May be reduced in milder weather. The higher the setting, the warmer your heater will get.

### Boost control - controls the amount of heat given later in the day

Normally leave boost setting at minimum. Turn up if more heat is required later in the day. Leaving the control on a higher setting will provide automatic boost each day.

### On/Off Switch

Leave on for heating season.



## Combined Storage Heaters

CXL/CXLN Models

### Input control - controls the temperature of the heater

Set to maximum during coldest weather. May be reduced in milder weather. The higher the setting, the warmer your heater will get.

### Boost control - controls the amount of heat given later in the day

Normally leave boost setting at minimum. Turn up if more heat is required later in the day. Leaving the control on a higher setting will provide automatic boost each day.

### Convactor Boost

#### On/Off Switch

Switch on if top up heat required. Neon light shows when boost is selected.

### Convactor Boost Heat Setting


Thermostat control to select your chosen comfort level.

### Convactor On/Off Switch

Leave on.


### Storage On/Off Switch

Leave on for heating season.



**WARNING:** Curtains and furniture should be at least 150mm (6") from storage heaters. Do not cover air outlet grilles.

## PLX/PLXN and TI Models



### Thermostat

Set control to appropriate position to give comfort level required. Heater will switch on and off as necessary, and a higher setting will make the room warmer.

### Time Clock - (dependent on model)

Can be set to switch heater on and off automatically. Either push tabs in or pull tabs forward for on periods, depending on model.

### Selector Switch

Auto: heater controlled by time switch.  
Off: heater off (clock still runs.)  
Man: heater on continuously.

### Lockable cover

### On/Off Switch

Leave on for heating season.


Heater can be hinged forward for easier cleaning.

## Wall Fan Heaters

### FX Models

For maximum economy, only use heater for boosting room temperature and turn off when not required. Model FX20E automatically switches off after a pre-set time.

### On/Off indicator



## Some important information about storage heating

### Safety

Where young children, elderly or infirm people may be left unsupervised in the vicinity of the heater, we recommend fitting a guard. Never cover the heater with clothes and allow at least 150mm clearance between the heater and any curtains.

### Fixing & Moving

Storage heaters are heavy and, for safety in use, they must be firmly fixed to a sound wall. Do not attempt to remove the heater from its mounting bracket without specialist assistance.

### Cleaning

Do not use abrasive cleaning powders or furniture polish on your storage heater. When not in use, the heater can be wiped over with a dry duster or damp cloth.

### Helplines

For help and advice about any aspect of your Dimplex heaters please call our Customer Services department or write to us at this address:-

Dimplex, Millbrook, Southampton SO15 0AW  
Customer Services 0870 727 0101